

SetRowNewValue

Function

The function **SetRowNewValue** sets new values for a row of defined object of *Structure* type.

Declaration

APIRET SetRowNewValue(HOBJ Id, unsigned int row, const UniValPtr value)

Parameters

The parameter *Id* defines the identifier of changed object and *value* defines new values and status of the object row. The parameter *row* determines the row index (from 1 ...).

Return code

Code	Description
API_OK	Values was sent to D2000 Server .
API_UnknownId	Object Id is unknown for the interface D2000 ObjApi . The interface D2000 ObjApi includes an internal list of used objects, which is filled at callings the functions <i>NewValueProc</i> , <i>NewDefProc</i> , <i>OpenObject</i> , <i>GetObjectValue</i> and <i>GetObjectId</i> . In this case, the object ID could not be get in the correct way via ObjAPI.
API_ValTypeError	The type of new object value is not the same as the value type in the system. A value change can cause unexpected problems during the runtime of D2000 Server .
API_ParamError	Invalid parameters.



Related pages:

[ObjApi - Executive functions](#)