

%LNG_GetLngNameFromIdx

%LNG_GetLngNameFromIdx Function

Function	The function gets a language name from its numeric identifier.		
Declaration	<pre>INT %LNG_GetLngNameFromIdx(TEXT in _lngIdx)</pre>		
Parameters	<table><tr><td>lngIdx</td><td>Numeric language identifier.</td></tr></table>	lngIdx	Numeric language identifier.
lngIdx	Numeric language identifier.		
Description	If the language given by the <i>_lngName</i> parameter is not defined or the language name is empty text, the function returns an invalid value.		
Example	<pre>BEGIN INT _lngIdx _lngIdx := %LNG_GetLngIdxFromName("SK") TEXT _lngName _lngName := %LNG_GetLngNameFromIdx(_lngIdx) END</pre>		



Related pages:

- [ESL extended functions](#)
- [Function arguments - types](#)
- [%LNG_GetCurrLngIdx Function](#)
- [%LNG_GetLngIdxFromName Function](#)
- [%HI_LNG_Translate Function](#)
- [%HI_LNG_GetCurrLngIdx Function](#)
- [Dictionary](#)