

StructStatMAX

%StructStatMAX function

Function

The function returns the maximal value from valid values of given structured variable column. Row range is defined by the parameters *first_row* a *last_row*. The result is a real number.

Declaration

```
REAL %StructStatMAX(  
    in StructVar^Column,  
    INT in first_row,  
    INT in last_row  
)
```

Parameters

| | |
|----------------------------|------------------------------|
| StructVar | Structured variable. |
| Column | Structured variable column. |
| first_row, last_row | Range of rows in the column. |

Example

```
%StructStatMAX(SV.Structure^Int, 4, 6)
```



Related pages:

[Implemented functions](#)
[Function arguments - types](#)