HI_GraphCorrectionLineEnable function

%HI_GraphCorrectionLineEnable function

Function

The function **%HI_GraphCorrectionStart** starts the correction of the flows in graph. This correction allows a user to correct a data curve in a graph using the mouse.

The function **%HI_GraphCorrectionStop** stops the correction of flows.

Declaration

```
%HI_GraphCorrectionLineEnable(
   INT in refId,
   INT in lineNr,
   BOOL in enable
 )
```

Parameters

refId	Reference to the graphic object of Graph type (reference variable).
lineNr	Number of line whose flow is changed.
enable	@True - the flow can be corrected @False - the flow cannot be corrected

After opening a graph, all flows in graphs are disabled for correction.

Related pages:

Graphic object manipulation functions
Function arguments - types
%HI_GraphGetLineData
OnGraphCorrectionSave
OnGraphCorrectionStop