

MaxImp

%MaxImp function

Old name

%MaxImpI

Function

The function returns the accession of the given integer variable for the time period elapsed. The result is an integer value.

Declaration

```
INT %MaxImp(  
    INT in Arg,  
    BOOL in ResetTrigger  
)
```

Parameters

Arg	Variable which accession is to be calculated. The function assumes, that value of the variable <i>Arg</i> increases within the calculation interval. (For example: electrometer status).
ResetTrigger	Change of the parameter into the TRUE state causes resetting the calculation.



Related pages:

[Implemented functions](#)
[Function arguments - types](#)