



# D2000 Installation

The web page <https://d2000.ipesoft.com/download/> will be displayed in the web browser.




Accept the license agreement and download the 64-bit version of D2000.






Unpack the downloaded installation package.






Run the **setup\_ips.exe** file to start the installation.




After running the installation, a dialogue window for choosing a language, in which the installation will run, will appear. Choose English.




The initial window of the installer guide will open next. It can be controlled by three buttons which enable us to move forward and backward in the dialogue or to cancel the installation altogether.






Confirm the license agreement and click the button Next.





Choose the installation of the Server type and click the button Next.


Warning: If there are one or more instances of the D2000 system on the computer, there will be a window for instance administration preceding this one.




The screenshot shows a Windows-style dialog box titled "D2000 System Installer Guide V12.0.61.2". The main heading is "Setting the parameters of the new instance". Below this, it says "Fill the name and directory of the new instance." There are three input sections: 1. "Instance name:" with a text box containing "D2000 V12.0.61 server". 2. "Instance destination directory: (this path will contain D2000\_EXE, D2Install, ...)" with a text box containing "C:\D2000\D2000\_V12.0.61\_server\" and a browse button "...". 3. "Creation mode:" with two radio buttons. The first is "Standard (recommended)" which is selected, with a description: "New instance of System D2000 will be properly installed on this computer. New instance will be added into instance list and could be removed or upgraded." The second is "Copy only" with a description: "Copy only creation mode just copy files of System D2000 to the target directory. No configuration will be provided, so that copied files could not be fully functional." At the bottom right are three buttons: "Back", "Next" (which is highlighted with a blue border), and "Cancel".

Set the name of the installed instance and the destination directory. Leave the parameter "Creation mode" set as Standard. The given instance name will be used in the *Start menu* after its installation.





Display of summarizing information about the entered parameters. After confirmation, the installation process will run and it can take some time.





Use the "Default configuration".

D2000 System Configuration Guide V12.00.061

IP mask and system directories

Insert the IP mask of network and select the path to the system directories.

IP mask:

255.255.255.0

D2000 directories paths:

Application: C:\D2000\D2000\_V12.0.61\_server\D2000\_APP ...

In the selected directory will be saved application files System D2000.

Logging: C:\D2000\D2000\_V12.0.61\_server\D2000\_EXE\Log ...

In the selected directory will be stored log information on system operation D2000 and its processes.

Back Next Finish

If needed, change the following parameters (in most cases, they are pre-set correctly)

- IP mask – the Subnet Mask parameter
- Application – the directory for saving configuration of created applications
- Logging – the directory for storing log files



D2000 System Configuration Guide V12.00.061

The support programs for D2000 Server

Choose which support programs you want to install and enter the licence file.

☒ Install the PostgreSQL  
Installs the PostgreSQL database management system.

☐ Install the support for HW keys  
Install the Sentinel Protection Installer essential for the proper functioning of hardware keys.

☐ Use the hardware key

☒ Use the software key

Back
Next
Finish

It is necessary to install the PostgreSQL database which is used for storing a configuration of applications. In the case of the Demo version, the support for HW keys, and the choice of the hardware key/software key is not necessary.

D2000 System Configuration Guide V12.00.061

Creating the shortcuts for D2000 System clients

Select the client, for which the shortcut should be created and their location.

Shortcut location:

☒ Desktop

☒ Start menu

☒ For all users


To set the shortcut parameters, double-click on the particular client name.

Add shortcut	Client	Parameters
<input checked="" type="checkbox"/>	D2000 Application manager	
<input checked="" type="checkbox"/>	D2000 CNF	
<input checked="" type="checkbox"/>	D2000 System Console	
<input checked="" type="checkbox"/>	D2000 HI	
<input checked="" type="checkbox"/>	D2000 GREDIT	
<input checked="" type="checkbox"/>	D2000 Reference documentation	
<input checked="" type="checkbox"/>	D2000 HI documentation	
<input checked="" type="checkbox"/>	Run DEMO_Basic1	--CREATEANDRUNAPP=DEMO_Basic1

Back
Next
Finish




Settings for the creation of the shortcuts for individual components. In most cases, the default setting is correct.




The choice "Run demo application" enables the creating and running of the demo application after the end of the installation. It is possible to save the set parameters of the installation. The last installation phase will run after clicking the button "Finish".






The window informs about the current running configuration process. Information about the success or failure of this process is shown as well.




Now the instance of the D2000 system is installed, configured and ready to be used. After clicking the button "Ok", the button "Complete" will be available, shown on the previous slide. By clicking the button, the installation will be completed and the DEMO\_Basic1 application will be created.






An Internet page “after install” will appear and at the same time, the DEMO\_Basic1 application will start running.




The Application Manager presents the course of creating the DEMO\_Basic1 application and its start. After starting the application, two client processes – HI and GR with the logged-in user SystemD2000 (password: SystemD2000) – will start automatically.






Human Interface – D2000 HI will open with the starting scheme S.Welcome. By clicking on the button “Explore”, the main summarizing scheme of the DEMO application will open.






There are demonstrations and the usage of the basic types of graphic objects displayed in the DEMO application. In the section "Pictures", there are two examples of practical usage of the graphic objects – in the demonstration scheme of watching the process of charging and discharging a battery and technological scheme of a gas station.




On the other tab of the web browser, there will be a welcoming scheme S.Welcome displayed in the thin client environment. It is the same scheme S. Welcome as is displayed in the D2000 HI window. The description of its functionality and usage is thus the same.






Graphic editor – GR serves for creating visualization and a complete configuration of the application. Currently, it offers configuration of the initial scheme from the previous slide (S.Welcome). If it is changed and saved, the result will be visible in HI (if it is not visible in HI, there is a need to logout and login again).






The DEMO\_Basic1 application can be started individually by clicking on the link "Run DEMO\_Basic1".

After the applications start, also the processes D2000 HI and D2000 GR will run automatically and in the web browser, the thin client with the scheme S. Welcome will appear.



Without a paid license, the application in the DEMO mode will be automatically shut down after an hour. Before that, a system message about the time limitation of the license validity appears. The license will be automatically renewed if parameters of the Internet connection are set correctly and sending of diagnostic data to the central Ipesoft server is allowed according to the following slide.





By the choice File/Settings in the Application manager, the Settings window is opened. The correct parameter values of our internet connection can be configured here. The button "Auto-detect" sets everything automatically. If the proxy server is used, the correct parameters of the proxy server must be entered. The correctness of parameters is tested by clicking the button "Test connection".