

HI_LNG_GetCurrLngIdx

%HI_LNG_GetCurrLngIdx function

Function The function returns the identifier of the current language.

Declaration

```
INT %HI_LNG_GetCurrLngIdx()
```

Parameters None.

Return value Return value is **Int** type.



Related pages:

[Active picture manipulation functions](#)
[Function arguments - types](#)