

HI_SetModeZoom

%HI_SetModeZoom function

Function

The function sets Picture to the zoom mode (symmetric zoom). It is usable only for pictures with zoom ([R esize with zoom](#)) or layers ([Resize with layers](#)). When applying this function, the picture cannot be controlled by [popup menu](#).

Declaration

```
%HI_SetModeZoom( )
```

Parameters

No parameters.

Note

This function is available also in [%HIX_ version](#).

**Related pages:**

- [Active picture manipulation functions](#)
- [Picture local variables](#)
- [Function arguments - type](#)