

# HI\_SetModeMove

## %HI\_SetModeMove function

---

**Function**

The function sets Picture to the "MOVE" mode from the script. Picture movement is possible with the "PACKY" mode. When applying this function, the picture cannot be controlled by [popup menu](#).

**Declaration**

```
%HI_SetModeMove ( )
```

**Parameters**

No parameters.

**Note**

This function is available also in [%HIX\\_version](#).

---

**Related pages:**

[Active picture manipulation functions](#)  
[Picture local variables](#)  
[Function arguments - type](#)