

HI_SetLineTerminator

%HI_SetLineTerminator function

Function

The function sets the form of lines and sublines termination in polyline.

Declaration

```
%HI_SetLineTerminator(  
    INT in refId,  
    BOOL in _bStart,  
    BOOL in _bSublines,  
    INT in _type  
)
```

Parameters

refId	Reference to displayer (reference variable).
bStart	<ul style="list-style-type: none">• @TRUE - basepoint• @FALSE - terminal point
bSublines	<ul style="list-style-type: none">• @TRUE - sublines
type	Number as it is defined in graphics editor : <ul style="list-style-type: none">• 0 - none• 1 - arrow• 2 - sharp arrow• 3 - thick arrow• 4 - ring• 5 - square



Related pages:

[Active picture manipulation functions](#)
[Function arguments - type](#)