

# HI\_SetPLineNumItems

## %HI\_SetPLineNumItems function

### Function

The function sets number of line segments in polyline from the script.

### Declaration

```
%HI_SetPLineNumItems(  
    INT in _refId,  
    INT in _num  
)
```

### Parameters

<b>refId</b>	Reference on displayer ( <a href="#">reference variable</a> ).
<b>num</b>	Number of line segments.

### Note

Setting the number of line segments in polyline:

- In the case that less line segments are defines as it is set then the length of new lines is 0 on X /Y axis.
- The lines are set with the functions [Hi\\_SetdistX](#), [Hi\\_SetdistY](#).
- The lines must be added first, then it is possible to set them.



### Related pages:

[Graphic object manipulation functions](#)  
[Function arguments - types](#)