

# HI\_ReportPrint

## %HI\_ReportPrint function

---

### Function

The function **%HI\_ReportPrint** allows to print the display of the Report type, that is placed in the picture ([Control function](#)).

### Declaration

```
%HI_ReportPrint(  
    INT in refId  
)
```

### Parameters

<b>refId</b>	Reference to graphic object ( <a href="#">reference variable</a> ).
--------------	---

### Description

The function allows to print the display of **Report** type. The display is defined by the reference variable *refId*.

The printer, that prints the report, is given by the setting of the report interpreter. For example: the printer for a report of Excel type, is defined by the configuration of the MS Excel.



#### Related pages:

[Graphic object manipulation functions](#)  
[Function arguments - types](#)