HI_ReportPrint

%HI_ReportPrint function

Function

The function **%HI_ReportPrint** allows to print the displayer of the Report type, that is placed in the picture (Control function).

Declaration

```
%HI_ReportPrint(
   INT in refId
 )
```

Parameters

refId	Reference to graphic object (reference variable).

Description

The function allows to print the displayer of **Report** type. The displayer is defined by the reference variable *refId*.

The printer, that prints the report, is given by the setting of the report interpreter. For example: the printer for a report of Excel type, is defined by the configuration of the MS Excel.

Related pages:

Graphic object manipulation functions
Function arguments - types