

# HI\_SetBrowserAutoRefresh

## %HI\_SetBrowserAutoRefresh, %HI\_GetBrowserAutoRefresh functions

### Function

The function **%HI\_SetBrowserAutoRefresh** enables/disables auto refresh in displayer of **Browser** type (control function), if the object **Table** is connected to it.

The function **%HI\_GetBrowserAutoRefresh** returns the setting of auto refresh in **Browser** displayer.

### Declaration

```
%HI_SetBrowserAutoRefresh(  
    INT in refId,  
    BOOL in autorefresh  
)  
  
BOOL %HI_GetBrowserAutoRefresh(  
    INT in refId  
)
```

### Parameters

<b>refId</b>	Reference to displayer ( <a href="#">reference variable</a> ).
<b>autorefresh</b>	The value of displayer. TRUE - auto refresh enabled, FALSE - auto refresh disabled.

### Note

It relates only to **Browser** displayer with the connected **Table**.



#### Related pages:

- [Graphic object manipulation functions](#)
- [Function arguments - types](#)