

SetDragDataText

%SetDragDataText, %GetDragDataText functions

Function	Function %SetDragDataText sets a text as a source of data for Drag&Drop . Function %GetDragDataText returns a text string that is transferred during Drag&Drop. If the function %IsDragData (0, _CF_TEXT) does not return @TRUE, the return value of this function is undefined.				
Declaration	<pre>%SetDragDataText(INT in refId, TEXT in text)</pre> <pre>TEXT %GetDragDataText(INT in refId)</pre>				
Parameters	<table><tr><td>refId</td><td>It always requires 0.</td></tr><tr><td>text</td><td>A text, which represents a source of data.</td></tr></table>	refId	It always requires 0.	text	A text, which represents a source of data.
refId	It always requires 0.				
text	A text, which represents a source of data.				
Return value	TEXT - returns the text value that is transferred during Drag&Drop.				



Related pages:

[Graphic object manipulation functions](#)
[Function arguments - types](#)