

SetInvalid

%SetInvalid function

Function

The function invalidates (sets the attribute Invalid) the value given by the parameter while the value type remains unchanged.

Declaration

```
UNIVAL %SetInvalid(  
    UNIVAL in expression  
)
```

Parameters

expression	Optional expression.
-------------------	----------------------

Note

The function may be used e.g. to invalidate any value.

Example

```
%SetInvalid(0)
```

Related topics

[%IsNull](#)



Related pages:

[Implemented functions](#)
[Function arguments - types](#)