

# GetColName

## %GetColName function

Function

The function returns the name of the specified structure column.

Declaration

TEXT %

**GetColName**

(

HBJ in objRef,

INT in index

)

Parameters

|        |                                                                                                             |
|--------|-------------------------------------------------------------------------------------------------------------|
| objRef | Reference to an object of <a href="#">Structure definition</a> or <a href="#">Structured variable</a> type. |
| index  | Column index.                                                                                               |

Example

The function returns the name of given column of specified structure (or structure definition) as a text. Column is given by its serial number. Expression of Hbj type returns an [object attribute](#) \HBJ.

```
%GetColName(SV.Structure\HBJ, 1)    ; returns the value of "Text"
%GetColName(SV.Structure\HBJ, 2)    ; returns the value of "Int"
%GetColName(SV.Structure\HBJ, 10)   ; returns invalid value
```

See also the attribute: [\HBJ](#)



**Related pages:**

- [Implemented functions](#)
- [Function arguments - types](#)