

# Trunc

## %Trunc function

### Function

The function modifies real parameter (its decimal part) to real number.

### Declaration

```
REAL %Trunc(  
    REAL in number  
)
```

### Parameters

number	Function argument.
--------	--------------------

### Example

```
REAL _A  
  
_A := %Trunc(15.237123)  
  
; (_A is 15)
```



Related pages:

[Implemented functions](#)

[Function arguments - types](#)