

StructStatMIN

%StructStatMIN function

Function

The function returns the minimal value from valid values of given structured variable column. Row range is defined by the parameters *first_row* a *last_row*.
The result is a real number.

Declaration

```
REAL %StructStatMIN(
    in StructVar^Column,
    INT in first_row,
    INT in last_row
)
```

Parameters

StructVar	Structured variable.
Column	Structured variable column.
first_row, last_row	Range of rows in the column.

Example

```
%StructStatMIN(SV.Structure^Int, 4, 6)
```



Related pages:

[Implemented functions](#)

[Function arguments - types](#)