

CNT_INSERT

CNT_INSERT action

Declaration

CNT_INSERT _hContainer, _key, _value

Parameters

_hContainer	in	Identifier of <i>Int</i> type - data container.
_key	in	Identifier of value in the container (possible types: <i>Bool</i> , <i>Real</i> , <i>Text</i> , <i>Time</i>). WARNING: the parameter may not be a structured identifier.
_value	in	Value to be inserted into the container. Possible value types: <i>Bool</i> , <i>Real</i> , <i>Text</i> , <i>Time</i> entire structured variable, structured variable row.

Description

The action inserts the value specified by the parameter *_value* into the [data container](#). The value in the container is identified by the key specified by the parameter *_key*.

If the container already contains a value with the same key, the action overwrites the value with the value given by the parameter *_value*. Container cannot contain two (or more) values with the same key.

Example

[Work with data container \(actions CNT_...\)](#).

 Related pages:

[Script actions](#)