

# %HI\_GraphCorrectionLineEnable function

**Function** The function **%HI\_GraphCorrectionStart** starts the correction of the flows in graph. This correction allows a user to correct a data curve in a graph using the mouse.

The function **%HI\_GraphCorrectionStop** stops the correction of flows.

**Declaration**

```
%HI_GraphCorrectionLineEnable(  
    INT in refId,  
    INT in lineNr,  
    BOOL in enable  
)
```

**Parameters**

refId	Reference to the graphic object of Graph type ( <a href="#">reference variable</a> ).
lineNr	Number of line whose flow is changed.
enable	@True - the flow can be corrected @False - the flow cannot be corrected

After opening a graph, all flows in graphs are disabled for correction.



**Related pages:**

- [Graphic object manipulation functions](#)
- [Function arguments - types](#)
- [%HI\\_GraphGetLineData](#)
- [OnGraphCorrectionSave](#)
- [OnGraphCorrectionStop](#)