

NtV

%NtV function

Function	Function sets the defined occurrence time for the given expression value. Result is a value of the same type as the expression.				
Declaration	<pre>UNIVAL %NtV(in Expression, TIME in Time)</pre>				
Parameters	<table><tr><td>Expression</td><td>Optional expression.</td></tr><tr><td>Time</td><td>Value of Absolute time type, that determines the time of the value of the expression <i>Expression</i>.</td></tr></table>	Expression	Optional expression.	Time	Value of Absolute time type, that determines the time of the value of the expression <i>Expression</i> .
Expression	Optional expression.				
Time	Value of Absolute time type, that determines the time of the value of the expression <i>Expression</i> .				
Example	<pre>%NtV(P.SpeedFilterSim_PB+5, U.UVAR_TA\TIM)</pre>				



Related pages:

- [Implemented functions](#)
- [Function arguments - types](#)