

# Example of reference file of REF type

```
STATION_NAME = BN1
PROTOCOL = PM_EL
DESCRIPT = Temperature measuring in Novaky Coal-mine
```

```
[0H_BN_°Heat_Rate]
D2TYPE = AI
ADDRESS1 = 0
ADDRESS2 = 10
DESCRIPT = Heat rate
TECH_UNIT = GJ/h
ARCHIV = YES
ARC_FILTER = 1
```

```
[0H_BN_Heat_Max_15min]
D2TYPE = AI
ADDRESS = 1
DESCRIPT = 1/4 hour maximum
TECH_UNIT = MWh
ARCHIV = YES
ARC_FILTERL = 1
ARC_FILTERN = 1.5
ARC_FILTERH = 2.1
```

```
[0H_BN_Heat_Boiler]
D2TYPE = AI
ADDRESS = PA,222,0
DESCRIPT = Heat on output from boiler
TECH_UNIT = °C
LIMITS = 0,0,100,100
```



## Related pages:

[Reference file of REF type](#)