

CNT_CREATE

CNT_CREATE action

Declaration

```
CNT_CREATE _hContainer [CASE_SENSITIVE]
```

Parameters

_hContainer	out	Identifier of <i>Int</i> type - data container.
-------------	-----	---

Description

The action creates an empty [data container](#). The owner of the container is running instance of the script. The container cannot be shared by other scripts. The keyword CASE_SENSITIVE ensures the comparison of the keys of inserted items based on differentiation of lowercase and uppercase letters. It is used only for the keys of *Text* type. The container is terminated by termination of the script or by execution of the action [CNT_DESTROY](#).

Example

[Work with data container \(actions CNT_...\)](#).



Related pages:

[Script actions](#)