

%HI_GraphCorrectionLineEnable function

Function

The function **%HI_GraphCorrectionStart** starts the correction of the flows in graph. This correction allows a user to correct a data curve in a graph using the mouse.

The function **%HI_GraphCorrectionStop** stops the correction of flows.

Declaration

```
%HI_GraphCorrectionLineEnable(  
    INT in refId,  
    INT in lineNr,  
    BOOL in enable  
)
```

Parameters

refId	Reference to the graphic object of Graph type (reference variable).
lineNr	Number of line whose flow is changed.
enable	@True - the flow can be corrected @False - the flow cannot be corrected

After opening a graph, all flows in graphs are disabled for correction.



Related pages:

- [Graphic object manipulation functions](#)
- [Function arguments - types](#)
- [%HI_GraphGetLineData](#)
- [OnGraphCorrectionSave](#)
- [OnGraphCorrectionStop](#)