Export subdirectory

Export subdirectory parameter

Parameter "export subdirectory" for the objects may be set in several ways:

- 1. Selecting the item Setting parameter Export subdirectory in Objects menu.
- 2. Setting the parameter as one of the basic configuration property when editing object.

Setting through Objects menu

Clicking on the item Setting parameter Export subdirectory in Objects menu in D2000 CNF opens the following dialog window.

System Object Applications				per of tags = 1581) - [Export	subdirectory]	- • ×
₽₽	Q	7*	Remove AM name	Maska:		• • • • • •
All objects Diagnostika Diagnostika Diagnostika L1 Diagnostika L1 System System System System System Text Report Text Report Text Report Text Report Text Report Diagnostika Topological Link Topological Node Diagnostika System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System System		U.d U.DobaPre U.Konfig_S U.MenoApli U.MenoDB	Object description Meno instancie archivu 1 Meno instancie archivu 2 Hladane meno v archive Celková doba chodu tej Meno aplikacie D2000 Meno archívnej DB Meno Konfiguracnej a Meno Trezorovej DB	Current value 1 BFALSE dba DBA H.Vypocet1 2 32555620 srvdev05 Test01 \Test01\Archiv\Archiv.db \Test01\SysCfg\SysCfg.db \Trezor\Trezor.db	Time 15: 12: 57.074 11-02-2010 15: 12: 57.074 11-02-2010 15: 12: 57.074 11-02-2010 07: 35:08.384 02-10-2008 14: 37: 28.909 14-10-2008 10: 40: 55.443 12-05-2010 06: 54: 06.839 02-10-2008 09: 59: 39.818 12-02-2010 12: 48: 00.001 02-04-2013 12: 28: 51.069 16-05-2008 09: 12: 29.749 11-09-2008 12: 24: 29.629 02-04-2013 12: 24: 29.629 02-04-2013 12: 24: 29.629 02-04-2013	
All objects User V	/ariab	e	Page 1/2 (22	2 objects)		
						đ

Export subdirectory for the objects may be set as follows:

- · According to membership in logical group. The object must exist just in one logical group, otherwise an empty string will be set. If the object belongs to the nested logical group, the value of "export subdirectory" is: "logical_group"/" logical_group".
- Direct setting.
- According to CVS\Repository directory.

Export subdirectory keeps the last set subdirectory.

Parameter settings

Membership in logical group

- 1. Select an object which belongs to some logical group. If the object does not belong to any logical group you can insert it in the configuration window, tab Groups.
- Set Exp. subdirectory according to Log. group. A modal window opens which informs about successful/failed setting of 2. Click on button the parameter.
- 3. In the list of objects column Export subdirectory, you can see the logical group at objects for which this parameter is set.

Direct setting

1. Click on button Exp. subdirectory. It opens the modal window where you will set the subdirectory.

💷 Set exp. :	subdirectory	×
Nastavit na:	a\b	B
	Set	Cancel

- 2. Write a path directly into text field, then push the button Set.
- 3. In the list of objects column Export subdirectory, you can see the value of export subdirectory at objects for which this parameter is set.

According to CVS\Repository directory

1. Click on button Exp. subdirectory. It opens the modal window where you will set the subdirectory.

	Set exp. subdirectory
	Nastavit na:
	Set Cancel
5	Then click on button OK . If CVS subdirectory with <i>Repository file</i> is not placed in that directory, the user can cancel the action or use the selected path but without the path to XML Repository folder at the beginning.
	Warning (10-08-2011 12:36:34)
	There is no CVS subdirectory in this directory! Use selected path and cut XML Repository subdir?
	<u>Y</u> es <u>N</u> o

3. In the list of objects - column Export subdirectory, you can see the value of export subdirectory at objects for which this parameter is set.

Setting in configuration window for object

The parameter is set in the configuration window for object (the parameter Export subdir) in two ways:

- 1. Direct entering to the edit field.
- 2. Clicking the button ..., which opens the window to search the required directory with CVS. Click the OK button to confirm your selection. If CVS subdirectory with *Repository file* is not placed in that directory, the user can cancel the action or use the selected path but without the path to XML Repository folder at the beginning.

Related pages:			
Object menu Import from CNF Editing objects			