

HI_LogOut

%HI_LogOut

Function

The function causes the logout of the currently logged in user.

Declaration

```
%HI_LogOut ( )
```

Parameters

No parameters.

Description

The function calling causes the logout of the currently logged in user.

**Related pages:**

[Active picture manipulation functions](#)
[Function arguments - types](#)