HI_GetPictureScrollY

%HI_GetPictureScrollY function

Function	Function **%HI_GetPictureScrollY** gets back the value of the upper left point of zooming scheme on axis Y
Declaration	`%HI_GetPictureScrollY()`
Parameters	No parameters.
Note 1	Function %HI_GetPictureScroll after calling %HI_SetPictureScroll gets back rounded value of the setting.
Note 2	This function is available also in %HIX_ version.

Related pages:

Active picture manipulation functions
Function arguments - types