

HI_GetPictureConfigHeight

%HI_GetPictureConfigWidth, %HI_GetPictureConfigHeight functions

Function Function %HI_GetPictureConfigWidth returns the width of picture, %HI_GetPictureConfigHeight returns the height of picture.

Declaration

```
INT %HI_GetPictureConfigWidth()  
  
INT %HI_GetPictureConfigHeight()
```

Parameters

No parameters.

Example

```
INT _dx  
INT _dy  
  
_dx := %HI_GetPictureConfigWidth()  
_dy := %HI_GetPictureConfigHeight()
```

Note

This function is available also in [%HIX_ version](#).



Related pages:

[Active picture manipulation functions](#)
[Function arguments - types](#)