

HI_GetFontColorRE

%HI_GetFontColorRE, %HI_SetFontColorRE functions

Function	The function %HI_SetFontColorRE sets a font color to selected text in the graphic object Text entry field of RichEdit type (control function). The function %HI_GetFontColorRE retrieves the font color of selected text in the graphic object Text entry field of RichEdit type.				
Declaration	<pre>%HI_SetFontColorRE(INT in refId, INT in fontColor) INT %HI_GetFontColor(INT in refId)</pre>				
Parameters	<table><tr><td>refId</td><td>Reference to graphic object Text entry field of RichEdit type (reference variable).</td></tr><tr><td>fontColor</td><td>Font color of the selected text in the graphic object Text entry field of RichEdit type.</td></tr></table>	refId	Reference to graphic object Text entry field of RichEdit type (reference variable).	fontColor	Font color of the selected text in the graphic object Text entry field of RichEdit type.
refId	Reference to graphic object Text entry field of RichEdit type (reference variable).				
fontColor	Font color of the selected text in the graphic object Text entry field of RichEdit type.				



Related pages:

[Graphic object manipulation functions](#)
[Function arguments - types](#)