

# HI\_GetBrowserRowCount

## %HI\_GetBrowserRowCount function

### Function

The function **%HI\_GetBrowserRowCount** retrieves the number of rows of currently displayed page of displayer of **Browser** type.

### Declaration

```
INT %HI_GetBrowserRowCount(  
    INT in refId,  
)
```

### Parameters

**refId** Reference to displayer ([reference variable](#)).

### Return value

Number of rows of currently displayed page of the displayer of **Browser** type.



#### Related pages:

[Graphic object manipulation functions](#)  
[Function arguments - types](#)