

HI_GetConnectToKernelStatus

%HI_GetConnectToKernelStatus function

Function

The function retrieves the connection status between the [D2000 HI](#) process and the [D2000 Server](#) process within a [multiserver system](#).

Declaration

```
HBJHI_GetConnectToKernelStatus(  
    INT in kernelNr  
)
```

Parameters

kernelNr	Number of D2000 Server within multiserver system.
-----------------	--

Return value

The function returns a value of *int* type. Possible return values:

- 0 - the **D2000 HI** process is connected to the **D2000 Server** process and an user is logged on
- 1 - the **D2000 HI** process is connected to the **D2000 Server** process a and no user is logged on
- 2 - the **D2000 HI** process is not connected to the **D2000 Server** process



Related pages:

[Active picture manipulation function](#)
[Function arguments - types](#)