

HI_CloseRow

%HI_CloseRow function

Function

The function terminates updating of the row values of the object of Structured variable ([Control function](#)).

Declaration

```
INT %HI_CloseRow(
    HBJ in refToStruct,
    INT in index
)
```

Parameters

refToStruct	Reference to the object of the Structured variable type.
index	Structured variable row.

Description

The function terminates updating the values of the structured variable row defined by the parameter *index*. The structured variable is defined by the parameter *refToStruct* of HBJ type (for example: [SV.Structure](#)\HBJ). Value of the parameter *index* is not checked because of the size of the structured variable.

Example

Termination of updating the values of the row 5 of the structured variable *SV.Structure*:

```
_retCode := %HI_CloseRow(SV.Structure\HBJ, 5)
```



Related pages:

- [Active picture manipulation functions](#)
- [Indexed local variables](#)
- [Function arguments - types](#)