

# HI\_AddItem

## %HI\_AddItem function

### Function

The function adds a row to the specified Windows control of [List box](#) type ([Control function](#)).

### Declaration

```
%HI_AddItem(  
    INT in refId,  
    TEXT in itemText  
    [, HBJ in beforeItemIdx]  
)
```

### Parameters

<b>refId</b>	Reference to graphic object ( <a href="#">reference variable</a> ).
<b>itemText</b>	Text displayed in the added row.
<b>beforeItemIdx</b>	Index of the row, before which the added row will be inserted.

### Description

The function allows to add the row to the list box. The list box is defined by the reference variable *refId*. Text of the row is defined by the parameter *itemText*. If the parameter *beforeItemIdx* is not entered, the item will be added to the end. If it is entered, its value defines the index of the item, before which the new item will be inserted.

Rows are numbered from 1...



### Related pages:

[Graphic object manipulation functions](#)  
[Function arguments - types](#)