# HI_GetForeColor

## %HI_GetForeColor, %HI_SetForeColor functions

**Function**

The function **%HI_SetForeColor** sets the fore part color of the graphic object (Control function).

The function **%HI_GetForeColor** detects the fore part color of the graphic object.

**Declaration**

```
%HI_SetForeColor(
   INT in refId,
   INT in color
 )

 INT %HI_GetForeColor(
   INT in refId
 )
```

**Parameters**

| | |
|---|---|
| **refId** | Reference to graphic object (`reference variable`). |
| **color** | RGB index of color. |

**Note**

The functions use a color, that is expressed by RGB index. RGB index is a integer number, that express the color representation of the color components - red (R), green (G) and blue (B) in the result color.

The function %MakeRGB allows to form the color from individual color components.

**Related pages:**

Graphic object manipulation functions
Function arguments - types