

HI_GetBrowserCountVisibleRows

%HI_GetBrowserCountVisibleRows function

Function

The function **%HI_GetBrowserCountVisibleRows** retrieves the number of currently visible rows of currently displayed page of displayer of **Browser** type.

Declaration

```
INT %HI_GetBrowserCountVisibleRows(  
    INT in refId,  
)
```

Parameters

refId Reference to displayer ([reference variable](#)).

Return value

Number of currently visible rows of currently displayed page of the displayer of **Browser** type.



Related pages:

[Graphic object manipulation functions](#)
[Function arguments - types](#)