

HI_SetPictureSize

%HI_SetPictureSize function

Function

The function sets the minimal size of the picture.

Declaration

```
%HI_SetPictureSize(  
    INT in x,  
    INT in y,  
    BOOL in inside := @TRUE  
)
```

Parameters

x	Picture width. Special values: 0 - disables to maximize or minimize the picture, y is not important 1 - maximizes the picture, y is not important 2 - minimizes the picture, y is not important any other - sets the picture width according to the value
y	Picture height.
inside	Dimensions settings: <ul style="list-style-type: none">• @TRUE - dimensions are aimed for inner space of picture window, size of window is set according to these parameters + according to frame and title bar size• @FALSE - dimensions for the picture window

Note 1

The function is used only for pictures, that are not subpictures (they are not placed in other picture).

Note 2

This function is available also in [%HIX_version](#).



Related pages:

- [Active picture manipulation functions](#)
- [Function arguments - types](#)