

HI_SetPictureTitle

%HI_SetPictureTitle function

Function

The function sets the in the picture window title bar ([Control function](#)).

Declaration

```
%HI_SetPictureTitle(  
    TEXT in newTitle  
)
```

Parameters

newTitle	Text to display in the picture window title bar.
-----------------	--

Note 1

The parameter *newTitle* contains a text, that will be displayed in the picture window title bar. The text generated by the system will be replaced.

Note 2

This function is available also in [%HIX_ version](#).



Related pages:

[Active picture manipulation functions](#)
[Function arguments - types](#)