

HI_SetModeCtrl

%HI_SetModeCtrl function

Function

The function sets Picture to the CONTROL mode from the script. The modes MOVE or ZOOM are cancelled. When applying this function, the picture cannot be controlled by [popup menu](#).

Declaration

```
%HI_SetModeCtrl()
```

Parameters

No parameters.

Note

This function is available also in [%HIX_ version](#).

**Related pages:**

- [Active picture manipulation functions](#)
- [Picture local variables](#)
- [Function arguments - type](#)