

# TestStatus

## TestStatus function

### Function

The function returns TRUE, if status of object is the same as particular one which is defined by parameter **Stat**. If not, it returns FALSE.

Status name	Meaning
Normal	Valid value
Undefined	Undefined value
Out of Range	Out of range
Error	Error
Div by Zero	Dividing by zero

### Declaration

```
= TestStatus(DDEreference,Stat)
```

### Parameters

DDEreference	DDE reference in the format <a href="#">D_2000 STATUS!objname</a> or <a href="#">D_2000 ARCH_STATUS!lname</a> .
Stat	Status: InLimit, VLL, LL, HL, VHL, Transient, Default, Weak, Weak CMD, Weak ANS, Limits problem.

### Example

```
= TestStatus(D_2000| STATUS!U.Kx_O2_Ref_Plyn,Normal)
```



Related pages:

[Implemented function](#)