

# HI\_GetMonitorSizeY

## %HI\_GetMonitorSizeY function

---

**Function**

The function %HI\_GetMonitorSizeY gets back the vertical screen resolution.

**Declaration**

```
INT %HI_GetMonitorSizeY()
```

**Parameters**

No parameters.

**Description**

The function gets back the vertical screen resolution.

---

**Related pages:**

- [Active picture manipulation functions](#)
- [Picture local variables](#)
- [Function arguments - types](#)