

# ARC\_Unwrite

## %ARC\_Unwrite function

---

**Function**

The function suppresses writing values of specified object of the [Historical value](#) type into the archive database and deletes original values.

**Declaration**

```
%ARC_Unwrite()
```

**Parameters**

None.

**Description**

If a value of historical value is determined by the function **%ARC\_Unwrite()**, the value will not be written into the archive database and possible value with the same time will be deleted in the database.

**Example**

```
(H.Sinus > 0) ?  
[H.Sinus] : [%ARC_Unwrite()]
```

The example above allows only writing the values which are greater than 0 into the archive database.

---

**Related pages:**

[Functions for calculated historical values](#)  
[Function arguments - types](#)