

# Users

The D2000 system allows creating and defining parameters of a new user by means of an object of **User** type. The [D2000 CNF](#) process allows working with such objects. Using such an object allows defining user name, password, expiration time, access rights and actions which are enabled in the D2000 system.

**Note:** Starting with D2000 version 7.02.009 the object of **User** type has an integer value equal to number of user's logons to system (specifically logons to [D2000 HI](#), [D2000 GrEditor](#), [D2000 CNF](#), [D2000 Application Manager](#), [D2000 DDE Server](#), [D2000 System Console](#), [D2000 Tell](#), [D2000 Browser](#) processes).



## Related pages:

- [Create a new user](#)
- [Configuration of user parameters](#)
- [User's access to D2000 system objects](#)
- [User - Console](#)
- [ReadOnly mode](#)