Setting of full monitoring (Users)

User - setting of full monitoring

The full monitoring is activated by the setting of application parameter **AuditDepth_USER** (the application parameter) on the value different from 0. The value represents the time depth of the stored information in months. The value 0 (or absence of parameter) deactivates the monitoring.

The full identification of **AuditDepth_USER** is:

HKEY_LOCAL_MACHINE\SOFTWARE\Ipesoft\instance\cfg_ApplicationName\KERNEL\AuditDepth_USER

A type of parameter is *DWORD*.

If the monitoring is activated, the system saves the required information into the monitoring database of the application.

When the system starts and then periodically (every 7th day in a month at 10:00 p.m.) it checks the parameter setting. If **AuditDepth_USER** is different from 0, the system deletes the records older than the defined parameter (number of months). D2000 Server records the periodic scheduling of checking the parameters also into a log file as follows:

Periodic AUDIT Action: Next Check of Audit Depth will be at <dd.mm.rrrr hh:mi>

The status of monitoring may be found by a tell command for the D2000 Server - AUDIT_INFO.

The current configuration of users can be recorded (only once) into the monitoring database by the tell command AUDIT_INFO REINIT USER.

Related pages:

User - monitoring changes in configuration
Processing of generated files
Parameters for the D2000 Server process