

StationsApply

Declaration

```
void (_stdcall *StationsApply)(HOBj LnID, unsigned int Prot, void *AplPar);
```

Parameters

LnID	Line ID. A series of calls the interface function StationsApplyBack will be generated for all stations of the line.
Prot	Required protocol. All stations must contain the protocol in order to meet calling the function StationsApplyBack (constants OEM_Prot1 up to OEM_Prot16).
AplPar	Pointer that is passed into calling the function StationsApplyBack .

Description

After calling the function **StationsApply**, the process [D2000 KOM](#) calls the interface function [StationsApplyBack](#) for all stations of a line with called ID and given protocol and gives the parameter *AplPar*. The function mostly eliminates a necessity to keep own lists of stations.



Related pages:

[D2000 KomAPI - call-back functions](#)