

PointPar

PointPar structure

```
typedef struct _PointPar
{
    HOBJ          ppID;           // I/O tag ID
    HOBJ          ppParent;        // Parent ID - station
    char          ppName[32];      // Object name - I/O tag
    KomObjAddress ppAdr1;         // I/O tag address 1
    KomObjAddress ppAdr2;         // I/O tag address 2
    StationParPtr ppStaPar;       // StationPar of parent - station
    void          *ppPtVarPar;     // Parameters depending on protocol
    KomUniVal    *ppPtVal;        // Value
} PointPar;
```

Structure *PointPar* defines the parameters of the [I/O tag](#) objects. All the parameters are read-only, except for *ppPtVarPar*.

ppID

I/O tag ID (HOBJ)

ppParent

ID (HOBJ) of the I/O tag parent (station)

pName

I/O tag name

ppAdr1

I/O tag address 1

ppAdr2

I/O tag address 2

ppStaPar

Pointer to a structure [StationPar](#), which is the I/O tag parent (station).

ppPtVarPar

Pointer to a user structure. The user can place a pointer here to his own structure with auxiliary parameters for the I/O tag.

ppPtVal

KomUniVal structure – I/O tag value



Related pages:

[D2000 KomAPI - interface structures](#)