

HI_SetColumnMetadata

%HI_GetColumnMetadata, %HI_SetColumnMetadata functions

Function **%HI_GetColumnMetadata** function gets back a text value of metadata (according to defined key) that are assigned to the column of the graphic object [Browser](#).
%HI_SetColumnMetadata function sets a new text value of metadata (according to defined key) that are assigned to the column of the graphic object [Browser](#).

Declaration

```
TEXT %HI_GetColumnMetadata(  
    INT in _refId,  
    INT in _index,  
    TEXT in _key  
)  
  
BOOL %HI_SetColumnMetadata(  
    INT in _refId,  
    INT in _index,  
    TEXT in _key,  
    TEXT in _value,  
    BOOL in _bOverWrite  
)
```


Parameters

_refId	Reference to the graphic object (reference variable).
_index	Consecutive number of the column.
_key	Key which specified metadata.
_value	New value of metadata.
_bOverWrite	TRUE - either metadata are inserted (if they do not exist) or the value of existing metadata is updated. FALSE - either metadata are inserted (if metadata do not exist) or the existing value of metadata is kept.

Description **%HI_GetColumnMetadata** function gets back the text value of metadata (according to the defined key) which is assigned to column of the *Browser* graphic object.
%HI_SetColumnMetadata function sets new metadata (according to defined key) to column of *Browser* graphic object.

Note 1 Configuration of [metadata](#) for column of the graphic object *Browser*.
%HI_SetColumnMetadata function applies the change of metadata only on the running instance of picture.

Note 2 These functions are available also in [%HIX_version](#).

 **Related pages:**
[Graphic object manipulation functions](#)
[Function arguments - types](#)