

# HI\_ResetGraphZoom

## %HI\_ResetGraphZoom function

### Function

The function cancels the zoom used for given axis in displayer of [Graph](#) or [XY Graph](#) types.

### Declaration

```
%HI_ResetGraphZoom(  
    INT in refId,  
    BOOL in bResetX,  
    BOOL in bResetY,  
)
```

### Parameters

<b>refId</b>	Reference to displayer ( <a href="#">reference variable</a> ).
<b>bResetX</b>	Cancels the zoom used on the X-axis ( <a href="#">time zoom</a> ). Possible values: <ul style="list-style-type: none"><li>• @TRUE - cancel the zoom</li><li>• @FALSE - no change</li></ul>
<b>bResetY</b>	Cancels the zoom used on Y-axis ( <a href="#">value zoom</a> ). Possible values: <ul style="list-style-type: none"><li>• @TRUE - cancel the zoom</li><li>• @FALSE - no change</li></ul>

### Example

```
%HI_ResetGraphZoom(_Graph, @TRUE, @FALSE)
```

The function cancels the zoom used on X-axis ([time zoom](#)) and the zoom on Y-axis (if used) remains unchanged.



### Related pages:

[Graphic object manipulation functions](#)  
[Function arguments - types](#)