

HI_SetAXRefProp

%HI_SetAXRefProp function

Function

Declaration

The function sets the given variable to the value defined by the parameter *value*.

```
%HI_SetAXRefProp(  
    INT in refID,  
    TEXT in variableName,  
        in value  
)
```

Parameters

refId	Reference to ActiveX object (reference variable) or interface returned by calling the function HI_GetAXProp .
variableName	Name of the variable to set.
value	Value (of required type) to set.

Description

The function set the defined variable using the reference to the ActiveX object.



Related pages:

[ActiveX object manipulation functions](#)

[Function arguments - types](#)