

Requirement for value of object flag

The format of [DDE reference](#) that enables to get the value of object flag is:

= D_2000|FLAGS!objname

D_2000 - DDE Server name (required)

FLAGS - requirement for value of object flag

objname - object name

DDE reference returns a string. If the object flag is TRUE, the proper character (A..P) is in the string. The function [IsFlag](#) returns the value of particular flag.

The example of DDE reference is - [here](#).



Related pages:

[Instantaneous values](#)

[Requirement for object value](#)

[Requirement for time of value assignment](#)

[Requirement for status of object value](#)